

READ ME FIRST!

INSTRUCTION VIDEOS:

www.LOLsurprise.com



AGES 6+
SKUs: 593539, 593546, 593621

CONTENTS

- A. 1 FLYER
- B. 1 BOTTLE
- C. 1 CHARGING CABLE



BATTERY REPLACEMENT FOR BOTTLE

Before beginning, an adult must install fresh alkaline batteries. Here's how:

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the bottom of the unit.
2. Install three (3) new 1.5V AAA (LR03) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.



BATTERY SAFETY INFORMATION

- Keep these instructions for future reference.
- Use only size "AAA" (LR03) alkaline batteries (3 required).
- Charging of rechargeable batteries should only be done under adult supervision.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instruction.
- Always remove exhausted or dead batteries from the product.
- Dispose of dead batteries properly: do not burn or bury them.
- Do not attempt to recharge non-rechargeable batteries.
- Avoid short-circuiting battery terminals.
- Remove batteries before placing the unit into storage for a prolonged period of time.

WARNING

Risk of eye injuries. Do not fly near face to avoid injury.

- ADULT SUPERVISION REQUIRED when children are playing with flyer.
- DO NOT touch spinning propellers.
- Never use near steps, pools, or areas that may be hazardous to a child.
- WARNING: This toy produces flashes that may trigger epilepsy in sensitized individuals.

IMPORTANT INFORMATION

- **Play with flyer in a large open room, free of furniture.**
- **Magic Flyer is intended to be flown indoors only.**
- Please keep this manual as it contains important information.
- Keep long hair tied back and loose apparel, such as shoestrings away from the rotating propellers.
- To control your flyer requires specific skills and should be taught and used under direct supervision of an adult.
- Do not modify the unit or flyer in any way.
- Do not use flyer in or near water or power lines.
- Always keep your eyes on the flyer to prevent it from landing or crashing near your head, body or other people.
- Regularly examine flyer, bottle, plugs and charger for any damage before use.
- Never operate product if it is damaged.
- Keep the toy away from direct sunlight and/or direct heat.
- Do not expose unit to moisture of any kind.
- Wipe the unit with a damp cloth, if needed.
- Always stand when playing with flyer so to avoid crashing into flyer while in flight.
- Always turn off flyer or bottle when not in use.
- Never hold or throw any objects into the spinning propellers.
- NOTE: The hovering level may vary at different ground color and material reflection.

Let's care for the environment!
The wheellie bin symbol indicates that the product and its batteries must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Caution: Modifications not authorized by the manufacturer may void users authority to operate this device. CAN ICES-3 (B)/NMB-3(B).


BATTERY REQUIREMENT FOR FLYER :

DC 3.7V / 100mAh / 0.37Wh
LI-POLY BATTERY
REQUIRED (INCLUDED)

This product is equipped with a LiPo rechargeable battery. Please pay attention to the following safety instructions.

- Do not dispose the battery in fire or heat.
- Do not use or leave the battery near a heat source such as a heater.
- Do not strike or throw the battery against a hard surface.
- Do not submerge the battery in water. Keep the battery in a cool dry environment.
- Only use the provided charging cord.
- Do not over-charge the battery.
- Do not connect the battery to an electrical outlet.
- Do not solder the battery or pierce the battery with a nail or other sharp object.
- Do not transport or store the battery with metal objects such as necklaces, hairpins etc.
- Do not disassemble or alter the battery.
- This toy contains a battery that is non-replaceable.


GET TO KNOW YOUR FLYER




DO'S AND DONT'S




NORMAL PLAY



MANUALLY OPEN BOTTLE




PLAY WITHOUT BOTTLE



HOW TO STOP FLYER

- Do not grab flyer by wings or propeller when stopping it. Grabbing them may cause damage.
- Use a book, magazine or a thick, flat item that will not damage flyer.




AFTER 1 MINUTE OF PLAY THE RED LIGHT WILL FLASH.

USE A BOOK OR THICK, FLAT ITEM TO PRESS THE TIP OF THE PROPELLER.

CHARGING YOUR FLYER

- Before charging, wait 15 minutes or more to let battery cool down.
- Charge your flyer for 25-30 minutes, or until light turns off.
- You will get approx 4 minutes of play time per every charge.



THIS TOY IS ONLY TO BE CONNECTED TO EQUIPMENT BEARING EITHER OF THE FOLLOWING SYMBOLS:



© 2023 MGA Entertainment Inc. L.O.L. SURPRISE™ and MAGIC FLYERS™ are trademarks of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA. Printed in China

US/CA - MGA Entertainment Inc. 9220 Winnetka Ave, Chatsworth, CA 91311, U.S.A. Tel: +1 (800) 222-4685
www.mgae.com/contact
UK - MGA Entertainment UK Ltd. 50 Presley Way, Crownhill, Milton Keynes, MK8 0ES, Bucks, UK. MGA Consumer Services P.O. Box 2040 Hockley, Essex, S55 4BF Tel: 0800 521 558 Email: ukconsumerservices@mgae.com
EU - MGA Entertainment (Netherlands) B.V. Baronie 68-70, 2404 XG, Alphen a/d Rijn, The Netherlands Tel: +31-172-758-010 Email: klantenservice@mgae.com
AU/NZ - Imported by MGA Entertainment Australia Pty Ltd. Suite 5.05, 32 Delhi Road, Macquarie Park NSW 2113. AU. Tel: 1 300 059 676 Email: au-sales@mgae.com

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com

Illustrations are for reference only. Styles may vary from actual contents.



0623-0-E/INT