



COLOR-CHANGE

- Color change will start at approximately 59°F (15°C), but best results occur if the ice water is chilled to approximately 32°F (0°C) or colder.
- Warm color change will start at approximately 100.4°F (38°C), but best results occur if the water is approximately 104°F (40°C).
- Only certain dolls change color.
- Color change will only work on certain parts of the doll's body or accessories. Not all included accessories change color.
- If color change does not work properly or quickly, the temperature of the doll's body may be too close to the temperature of the water.
- Color change temperatures may vary according to weather conditions.
- The color-change effect of the doll's body has a lengthy, but limited lifespan.

IMPORTANT INFORMATION

- Before beginning, cover the play area to protect from possible water damage.
- Your doll will either cry, spit, pee or change color. Collect them all to see each feature!
- For best results, fill the bottle and feed the doll two times.
- Do not place the doll in extremely hot water.
- Do not feed the doll extremely hot water.
- An adult must be present when children are playing with water.
- Do not store the dolls in direct sunlight for extended periods of time.
- Exposure to sunlight may deactivate color change feature.
- Squeeze out all water from the bottle and the doll after each use.
- Thoroughly drain the doll on a dry towel in a well-ventilated area after use and before storing.
- Air dry only. Do not place in the dryer or subject to excessive heat.
- Do not place dolls with fuzz in water as it may damage the fuzz.
- Boy characters are anatomically correct.

*** ⚠ WARNING**
An adult must be present and supervise when placing the doll in warm water, as the water may be hot.

www.LOLsurprise.com
©2020 MGA Entertainment, Inc.
L.O.L. SURPRISE!™ is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA.

MGA Entertainment, Inc.
9220 Winnetka Ave.
Chatsworth, CA 91311 U.S.A.
(800) 222-4685

MGA Entertainment UK Ltd. 50 Presley Way, Crownhill Milton Keynes, MK8 0ES Bucks, UK + 0800 521 558

MGA Entertainment (Netherlands) B.V. Klipperlaak 201, 2411 ND Bodegraven, NL Tel: +31 (0) 172-758 038 E-mail: klantenservice@mgae.com

Imported by MGA Entertainment Australia Pty Ltd Suite 2.02, 32 Delhi Road, Macquarie Park NSW 2113 1300 059 676

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com

Printed in China
0819-0 -E/INT

Please keep this manual as it contains important information. Illustrations are for reference only. Styles may vary from actual contents.



AGES 3+
ADULT SUPERVISION REQUIRED

⚠ WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

