



4



5



COLOR -CHANGE

- Color change will start at approximately 59°F (15°C), but best results occur if the ice water is chilled to approximately 32°F (0°C) or colder.
- Only certain pets change color.
- All runts will change color and will not retain water from the bottle.
- Color change will only work on certain parts of the pet's body or accessories. Not all included accessories change color.
- If color change does not work properly or quickly, the temperature of the pet's body may be too close to the temperature of the water.
- Color change temperatures may vary according to weather conditions.
- The color-change effect of the pet's body has a lengthy, but limited lifespan.
- Extended exposure to sunlight may deactivate color change feature.

IMPORTANT INFORMATION

- Before beginning, cover the play area to protect from possible water damage.
- Your pet will either cry, spit, pee or change color. Collect them all to see each feature!
- Some hamsters don't retain water or color change. Squeeze them to hear them squeak!
- For best results, fill the bottle and feed the pet two times.
- Do not place the pet in extremely hot water (over 109.4°F/43°C).
- Do not place fuzzy pets in water, as it may damage their flocking.
- Do not feed the pet extremely hot water.
- An adult must be present when children are playing with water.
- Do not store the pet in direct sunlight for extended periods of time.
- Squeeze out all water from the bottle and the pet after each use.
- Thoroughly drain the pet on a dry towel in a well-ventilated area after use and before storing.
- Air dry the pet only. Do not place in the dryer or subject to excessive heat.

www.LOLsurprise.com

©2020 MGA Entertainment, Inc.

L.O.L. SURPRISE!™ is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA.

MGA Entertainment, Inc.
9220 Winnetka Ave.
Chatsworth, CA 91311 U.S.A.
(800) 222-4685

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill
Milton Keynes, MK8 0ES
Bucks, UK
+ 0800 521 558

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404XG Alphen a/d Rijn,
The Netherlands
Tel: +31 (0) 172 758038
E-mail: klantenservice@mgae.com

Imported by MGA Entertainment Australia Pty Ltd
Suite 2.02, 32 Delhi Road, Macquarie Park NSW 2113
1300 059 676

The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com

Printed in China
0520-0-EINT

Please keep this manual as it contains important information.
Illustrations are for reference only. Styles may vary from actual contents.



♥ OWNER'S MANUAL ♥

WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

AGES 3+
ADULT SUPERVISION REQUIRED


1




2




3A



3B



3C



3D

