

# RAINBOW HIGH™

Age 6+

**WARNING:**  
CHOKING HAZARD—Small parts.  
Not for children under 3 years.


578352, 578369, 578376  
SKUs: 578383, 578390, 578406

## QUICK START

### CHANGING LEGS


As an added bonus, included are extra legs with pointed toes to ensure your doll can wear both flat-footed sandals and high heels. To switch between them, follow the below instructions.

1. Pull off the bottom part of the doll's legs. Make sure to pull from under the knee. (Fig. 1)
2. Insert the second pair of legs. Take note of the left (L) and right (R) legs. Each leg is keyed for correct placement. (Fig. 2)



### TYING THE SANDALS

One particular doll has sandals that tie around the ankle. To tie these kinds of shoes, wrap the string around the ankle a few times and secure it by looping it into a bow.



### FASHION ACCESSORIES NOTES

- The flat-style shoes will only fit dolls with flat feet.
- While so many accessories are interchangeable between Rainbow High™ dolls, not all included accessories will fit other dolls.

### CARE INSTRUCTIONS

The doll has a light coating of gel in the hair. If you would like to style the doll's hair, ask an adult or under adult supervision follow the steps below to remove the gel. Please note that the doll's hair will not appear the same after washing.

1. Remove the doll's clothes and set them aside to avoid getting them wet.
2. Wet your doll's hair completely with water and lather in a little shampoo. Optionally, you can also add a little conditioner. (Shampoo and conditioner are not included). Work in with your fingers or comb through the hair.
3. Rinse it off. Then, allow the hair to dry completely before brushing and styling.  
(DO NOT USE HOT WATER.)

### PACKAGING

- Please remove all packaging including tags, ties & tacking stitches before giving this product to a child.
- Illustrations are for reference only. Styles may vary from actual contents.

Please keep this manual as it contains important information.



0821-0-E/INT  
Printed in China

WWW.RAINBOWHIGH.COM

©2021 MGA Entertainment, Inc.

RAINBOW HIGH™ is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA.

The preferred method of contact for Customer Service is through our e-mail contact form at [www.mgae.com](http://www.mgae.com)

#COLLECTTHERAINBOW

**MGA Entertainment, Inc.**  
9220 Winnetka Ave. Chatsworth, CA 91311  
U.S.A.  
(800) 222-4685

**MGA Entertainment UK Ltd.**  
50 Presley Way, Crownhill, Milton Keynes,  
MK8 0ES, Bucks, UK  
+ 0800 521 558

**MGA Entertainment (Netherlands) B.V.**  
Baronie 68-70, 2404 XG Alphen a/d Rijn,  
The Netherlands  
Tel: +31 (0) 172 758038

**Imported by MGA Entertainment Australia Pty Ltd.**  
Suite 2.02, 32 Delhi Road  
Macquarie Park NSW 2113  
1300 059 676