IMPORTANT INFORMATION

- Before beginning, cover the play area to protect from possible water damage.
- Do not place the doll in extremely hot water (over 109.4°F/43°C).
 Do not feed the doll extremely hot water.
- An adult must be present when children are playing with water.
 Do not store the dolls in direct sunlight for extended periods of time.
- Exposure to sunlight may deactivate color change feature.
- · Squeeze out all water from the doll after each use.
- Thoroughly drain the doll on a dry towel in a well-ventilated area after use and before storing.

 Air dry the doll only, Do not place in the dryer or subject to excessive heat.
- Do not submerge the hair in water to avoid damaging it. When inserting the doll in water, cover the hair or only submerge the body.
- Do not wash hair with soap and water or subject it to very high heat in any manner, as it will irreparably damage the hair.
- If hair gets wet, use a dry towel to dry off and allow it to air dry.

www.LOLsurprise.com ©2022 MGA Entertainment, Inc.

©2022 MGA Entertainment, Inc.
L.O.L. SURPRISE!** and HAIR HAIR HAIR** are trademarks of MGA in the
U.S. and other countries. All logos, names, characters, likenesses,
images, slogans, and packaging appearance are the property of MGA.

MGA Entertainment, Inc.

9220 Winnetka Ave. Chatsworth, CA 91311 U.S.A. (800) 222-4685

MGA Entertainment UK Ltd. 50 Presley Way, Crownhill Milton Keynes, MK8 0ES Bucks, UK

+ 0800 521 558

MGA Entertainment (Netherlands) B.V. Baronie 68-70, 2404 XG Alphen a/d Rijn The Netherlands Tel: +31 (0) 172 758038

Imported by MGA Entertainment Australia Pty Ltd Suite 2.02, 32 Delhi Road, Macquarie Park NSW 2113 1300 059 676

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com


Printed in China 0322-0-F/INT

Please keep this manual as it contains important information.

Illustrations are for reference only. Styles may vary from actual contents.



AGES 3+ ADULT SUPERVISION REQUIRED SKU: 584445, 584452 WARNING: CHOKING HAZARD-Small parts. Not for children under 3 years.



USING THE HAIR ACCESSORIES

Comb: Gently brush the doll's hair with the comb.

Ballies: (Only included in some packs.) Wrap the hair ballies around the doll's hair once and then secure it in place by inserting one ball through the loop on the other side.

Hair Bow: (Only included in some packs.) Grab a strand of the doll's hair and wrap the hair bow around it. Hair Clip: Open the clips and place a strand of the doll's hair in between. Then

close the clip to secure the hair in place. Scrunchie: Grab a strand of the doll's hair and wrap the scrunchie around it.

COLOR -CHANGE

Use ice water, approximately 32°F (0°C) for best cold color change. • Warm color change will start at approximately 100.4°F (38°C), but best

results occur if the water is approximately 104°F (40°C). · Some dolls change color in cold and warm water! Try both! · Color change will only work on certain parts of the doll's body or

· If color change does not work properly or quickly, the temperature of the doll's body/ball may be too close to the temperature of the water. · Color change temperatures may vary according to weather conditions.

 The color-change effect of the doll's body has a lengthy, but limited lifespan.

· Hair does not change color. Avoid submerging in water.

accessories. Not all included accessories change color.

*/↑ WARNING

An adult must be present and supervise when placing the doll in warm water, as the water may be hot.